



Ole 97 Bridge, a look from upstream, after work was complete. Removed a lot of the under brush to encourage erosion of the creek bank on the right side.



Shoved bags of concrete in the footing undercut, piled rip-raft in front of and on top of the exposed concrete bags, then covered all with river gravel.

These two small boulders were in the middle of the creek bed diverting water toward footing. We moved them in front of the footing to hopefully divert water away from the footing.

Completed Work, you almost can't tell we were even there.





A look from the backside (downstream).



We're Finished, lets go back to Memphis!